



INSTALLATION NOTES:

1. OPEN DIRECTORY PANELS AS SHOWN.  
MAILBOX CABINET (NOT SHOWN).
2. LOCATE DIRECTORY ON WALL ABOVE HORIZONTAL
3. DRILL (4) 0.187 HOLES INTO WALL THRU MOUNTING HOLES PROVIDED IN DIRECTORY.
4. INSTALL PLASTIC EXPANSION INSERTS INTO HOLES IN WALL.
5. MOUNT DIRECTORY TO WALL USING #8 SHEET METAL SCREWS.
6. CLOSE DIRECTORY PANELS.

PRODUCT SERIES: D500 DIRECTORY INSTALLATION

**AF FLORENCE**  
**manufacturing company**

5935 Corporate Drive Manhattan, KS  
 www.auth-florence.com (800) 275-

A GIBRALTAR INDUSTRIES COMPANY

MODEL	REV
SCALE NONE	DATE 8/16/06
DRAWING NUMBER 66503	DRAWN BY SHEET
1747 CS2013	1 OF 1