



Best Price in the
UNIVERSE
A Mailbox Company

TWIN C2 and D2 ASSEMBLY INSTRUCTIONS

IMPORTANT NOTE:

Customers are required to contact local post office before installing the mailbox to ensure its correct placement and height at street.

Generally, mailboxes are installed at a height of 41-45 inches from road surface to inside floor of mailbox or point of mail entry (locked designs) and are set back 6-8 inches from the front face of curb or road edge to mailbox door.

To Facilitate Installation:

Completely assemble entire mailbox unit. Dig hole approximately 16 in. deep with post hole digger or shovel and install box using either wet or dry mix of concrete. Level box not post, with a slightly forward angle. Some temporary support may be necessary while concrete sets.

- 1** Bolt support brackets (A), to bottom of boxes. For newspaper holder option, attach newspaper holder to box, then attach bracket (A) to newspaper holder
- 2** Attach mailbox and brackets to pole.
- 3** Place assembled post into hole, line up box with curb, and add concrete.
- 4** If needed, drive a stake into ground 3 or 4 feet behind post. Tie a string from stake to top of post to keep unit plumb.



Call our experts today at (866) 685-7873